



Plain tile flashing instructions (pf1)

1. Locate rafter positions.
2. Remove 4 plain tiles to expose rafter (see instruction video)
3. Place the plain tile flashing(tf1) into position to leave rafter exposed above.
4. Secure plain tile flashing(tf1) to roof batten using 2x 25mm screws provided.
5. Place metal roof hook(ras1) and packer over the plain tile flashing(tf1) onto rafter (packer not required on 19mm battens)
6. Line the 2 holes on the roof anchor on the centre of the rafter secure through the predrilled packer with Heco roof screws provided.
7. fit the foam strip across the top of the flashing (tf1) and over the anchor (ras1)
8. Re fit the 3 plain tiles back above the metal roof hook(ras1) and plain tile flashing(tf1) to seal roof. (1 plain tile per fixing will be spare)
9. Fit the metal roof hook convertor(ras3) if required depending on rail.
10. Repeat process for desired number of fixings. (maximum 1200mm spacing)